
SMART EV CHARGER

X1-EVC7.2K X3-EVC11K / X3-EVC22K



Features

- Type 2 connector cable
- Multi protection and integrated Type A RCD Protection
- Visualization of operating status with LED and LCD (Optional)
- Wide operation temperature range
- Indoor or outdoor easy installation and integration into SolaX-storage systems
- Multi work mode (ECO Fast work mode and charging time setting etc)
- Integrated RFID function (optional)
- Remote setting and monitoring with APP and website
- Smart Dynamic load balance control



SMART EV CHARGER

Specification		X1-EVC7.2K	X3-EVC11K	X3-EVC22K
	Phases/Lines	Single Phase/L1+N+PE	3 Phase/L1+L2+L3+N+PE	3 Phase/L1+L2+L3+N+PE
AC Nominal Input	Voltage [V]	230±10%	400±10%	400±10%
	Frequency [Hz]	50/60	50/60	50/60
AC Nominal Output Interface	Voltage [V]	230±10%	400±10%	400±10%
	Current [A]	32	16	32
	Power [kW]	7.2	11	22
	Wi-Fi or 4G LTE	YES	YES	YES
	RS485	YES	YES	YES
	RFID	Option	Option	Option
	MQTT	YES		YES
	OCPP 1.6 (JSON)	YES	YES	YES
	LCD Screen	Option	Option	Option
	CT Clamps	X1 CT	X3 CT	X3 CT
	Housing Material		Plastic/Metal	
	Installation Method	Wall-mount		
	Wall-mount Bracket	Not necessary		
	Charging Outlet	One charging gun(Type 2)/Socket-outlet		
	Cable Length [m]	5		
Security Protection	Operating Temperature [°C]	-		
	Working Humidity [%]	- 30~ + 50 5%,95% without condensation		
		5%~95% without condensation		
	Working Altitude [m]	<2000		
	Degree of Protection	IP54		
	Application Site	Indoor/Outdoor		
	Cooling Concept	Natural cooling		
	Dimensions (mm)	249x142x370		
		Over/Under voltage protection,Overload protection,Shortcircuit protection,		
	Multiple Protection	Current leakage protection, Grounding protection, Surge protection,		
		Overtemperature protection		
	Integral Earth Leakage	30mA Type A RCD (EN 61008) + 6mA DC protection (EN 62955)		
	Protection Integral	Softin Type A Neb (EN 01000) I Offin De protection (EN 02333)		
	Encrypted Communication	TLS		
	Safety Standard	IEC 61851-1:2017, IEC 62196-2:2016		
	Built-in PEN fault technology	YES		
	Warranty [years]	5		
Advanced Functions	Charging Mode	ECO Mode: The charge power is continuously adjusted, in response to changes in generation of powerconsumption elsewhere in the home, thereby minimising the use of grid power. There are six level in the ECO Mode, from the first to the sixth level. In the first level, The range of the EV charging current from 0A to rated current, the EV may stop charging if the available surplus power falls below 1.4k' (4.2kW for 3phase). In the other five leves, the available surplus power falls below the the fixed value opower, such as 1.4kW (4.2kW for 3phase), the shortfall will be drawn from the grid at any time. Fast Mode: Will charge the EV at the fastest rate and will import grid electricity if there is insucient surplus generated power. The max charging power will be the minimum value of the rated power and the current permitted power.		
	Smart Boost	The Smart Boost function will charge the EV with a minimum kWh figure by a set time. Smart Boost is available only in ECO mode.		
	Boost Timer	When using ECO or Green charge modes, EV charger can be programmed to 'boost' the current charg at certain times. When boosting, the charge rate is set to maximum (just like FAST mode), regardless of the amount of available surplus power. This means that power may be drawn from the mains grid supplicating boost times.		
	Dynamic load balancing	Enable: Full dynamic load balancing allows you to charge as fast as possible at your chargin mode, protects the main fuse and ensures that you can use your electricity wherever it's needed. Disable: Allowed charging at max current in the charging period.		
	Smart gateway support	YES		